How to Change a Sign using the Microlift System


IMPORTANT: The Microlift system was designed to make changing in store signage and display items simple, fast and safe. All persons who will be required to use the system should be properly trained before using.

Follow these 6 easy steps!


- Using the Microlift pole position yourself central to the sign and yourself central to the sign and slightly behind.
- Slowly extend the pole, section by section, until the hook is level with the opening in the unit
- 3 Engage the hook in the opening
- Slowly collapse the pole, section by section, until the sign is at a comfortable working height (i.e. chest level). Release the pressure on the unit by allowing the unit to retract upwards. After a short distance the unit will lock down
- 5 Detach the sign Attach new sign.
- Reinsert the pole hook into the opening.Pull the unit down to release the brake and slowly extend the pole, section by section until the unit is in the fully up position. Remove the pole and collapse, section by section, until it is fully retracted




ATTENTION: If the sign rises to fast the automatic brake will engage. If this happens simply pull the sign down a foot (to release the brake) and continue to SLOWLY raise the sign until unit has completely retracted.





Using the Microlift pole position yourself central to the sign and slightly behind.



Slowly extend the pole, section by section, until the hook is level with the opening in the unit







until the sign is at a comfortable working height (i.e. chest level). Release the pressure on the unit by allowing the unit to retract upwards. After a short distance the unit will lock down.

Reinsert the pole hook into the opening. Pull the unit down to release the brake and slowly extend the pole, section by section until the unit is in the fully up position. Remove the pole and collapse, section by section, until it is fully retracted.